




Team Mapping Environment

One Note Template corresponding to eVSM application

VSM icons match eVSM application smart shapes

How to use hints



VSM icons from eVSM.

- Batch CO Time** : Changeover or Cleaning time per batch.
- Batch Volume** : Volume of output material
- Batch Weight** : Weight of one batch
- Batches per Campaign** : Number of batches per campaign
- Campaign CO Time** : Set up time when moving from one campaign to another
- Campaign Matri Loss** : Output weight material loss per campaign due to changeover and cleaning
- Changeover Material Loss** : The material loss per changeover. Typically trapped material that needs to be cleaned out or flushed through as a part of changeover
- Changeovers Per Period** : The number of changeovers that happen in a time period
- Density** : Density of output material
- Descriptor** : Descriptor
- Downtime** : Downtime Percent during the period a station is supposed to be running (does not include changeover periods, etc.)
- Inventory** : The number of items waiting to be worked upon
- Max Unit Capacity** : Max capacity in units per period
- Process Lead Time** : Lead time of material through this process.
- Scrap Yield Loss** : The percentage of scrap at this process/step.
- Stations** : The number of identical stations of this activity. Each additional station reduces the 'cycle time per unit'.
- Step Yield** : Output Weight / Input Weight
- Supplier Lead Time** : The time interval between placing an order with a supplier and receiving the materials.
- Time per Batch** : Time per batch
- Time Per Changeover** : The time required to switch a station from one production item to another.
- Transport Frequency** : Time Between
- Transport Time** : The time taken to deliver items.
- Unit Demand** : Demand in units per period
- Volume Demand** : Volume demand for each product
- Weight Demand** : Customer demand expressed directly in weight terms
- Weight Per Unit** : Weight per local output unit.

Glossary of Variables

- Using One Note**
- Best to disable "Snap to Grid" via Draw>Shapes pull-down arrow
 - Select all items on the current page. Ctrl+A
 - Copy the selected text or item to the Clipboard Ctrl+C
 - Paste the contents of the Clipboard Ctrl+V
 - To use a template shape first select, then CTRL+C to copy and CTRL+V to paste.
 - To copy the map to eVSM, use Ctrl+A, then Ctrl+C to select/copy the map and then in Visio use "Paste Special" > Picture (Enhanced Metafile)
 - To create your own editable file, follow these instructions:
 1. Click File, then Export
 2. Select Page, then export the file (be sure the page is selected before)

